





MicroSim® Evaluation Software

MicroSim®

Setting the standard for Desktop EDA™

Get set. This is no ordinary EDA test drive.

If you thought you were getting just a little demo ride, hold on. You're about to load your PC with advanced EDA capabilities—many of which are available only from MicroSim. This evaluation software is unique for another reason too. It enables you not only to see the newest innovations but also to actually USE many of them to create real, working circuits (restricted to relatively small designs).

On this CD-ROM you'll find evaluation versions of MicroSim's Desktop EDA family of products. You will also find on-line manuals, tutorials, and sample designs to use while trying out the software. You can evaluate MicroSim DesignLab—the world's first and only tightly integrated start-to-finish system for mixed analog/discrete digital/PLD/CPLD, and FPGA designs. If you're responsible strictly for simulation, try out MicroSim PSpice A/D which comes with our schematic editor, MicroSim Schematics. Use them with MicroSim PCBoards and you'll get a feel for what it's like to work within an integrated environment. The evaluation software also includes MicroSim PSpice Optimizer which you can purchase as an option.

If you have questions, please call our customer sales representatives. They know all about our software and are happy to answer your questions.

To order any MicroSim product, call us at 1-800-245-3022 or fax your order to 714-455-0554. Or contact your MicroSim dealer.

Evaluation Version Limitations

Our evaluation software enables you to try the features of our production version of MicroSim's family of products with the following limitations:

Schematic entry:

- Design entry limited to one schematic page (A or A4 size)
- A maximum of 50 symbols can be placed on the schematic
- A maximum of 10 symbol libraries can be configured
- A maximum of 20 symbols allowed in a user-created symbol library
- A maximum of 70 parts can be netlisted

Printed circuit board layout:

- A maximum of 30 components
- A maximum of 50 nets
- A maximum of 4 signal layers, 2 of which can be autorouted
- 33 specific footprints
- A maximum of 150 pins for autorouting

Mixed analog and digital simulation:

- All the functionality of the schematic function as listed above
- Circuit simulation limited to circuits with up to 64 nodes
- 10 transistors, 2 operational amplifiers, or 65 digital primitive devices, or a combination thereof, and 10 transmission lines with not more than 4 pairwise coupled lines
- Device characterization limited to diodes
- Stimulus generation limited to sine waves (analog) and clocks (digital)
- Sample library of approximately 30 analog and 130 digital parts

Analog optimization:

- Limited to 1 goal, 1 parameter, and 1 constraint

MicroSim®

Setting the standard for Desktop EDA™

MicroSim Corporation
20 Fairbanks
Irvine, CA 92618 USA

Sales: 800-245-3022
Phone: 714-770-3022
Fax: 714-455-0554
E-mail: sales@microsim.com
WWW: http://www.microsim.com

© 1997, MicroSim Corporation.
All rights reserved.

Thank you for your interest in MicroSim's Family of Products.

PC Installation Instructions

Windows 95:

1. Insert the MicroSim CD into your CD-ROM drive. Wait for the MicroSim screen to appear and follow the installation instructions.
2. If the MicroSim screen does not appear, select Run from the Start Menu and enter: *drive*:\SETUP.EXE (where *drive* is your CD-ROM drive). Wait for the MicroSim screen to appear and follow the installation instructions.

Windows NT:

1. Insert the MicroSim CD into your CD-ROM drive.
2. Select Run from the File menu of the Program Manager.
3. Enter: *drive*:\SETUP.EXE (where *drive* is your CD-ROM drive). Wait for the MicroSim screen to appear and follow the installation instructions.

See the Readme.wri file for last-minute information on this release.
To find out What's New in this Release and how to Get Started with MicroSim's programs, see the QuickStart tutorial located in the MicroSim program group.

System Requirements

To use MicroSim's products effectively, you must have the following:

Hardware:

Any 486 or Pentium PC
16 Mb RAM recommended
CD-ROM drive
Floating point coprocessor
Mouse

Operating System:

Microsoft® Windows® 95 or Windows NT™

MicroSim®
Setting the standard for Desktop EDA™
COPYRIGHT © 1997 MICROSIM CORP.
Includes
on-line
manuals.
MicroSim
Family of
Products
Evaluation
Software